

PANEL USER MANUEL

QBIT CONTROL WWW.QBITCONTROL.COM

1.	Mer	nu Tree							
2.	2. Main Screen								
2	.1.	Working Mode 4							
2	.2.	Set Temperature							
2	.3.	Warning And Alarm Report							
3.	Mai	n Menu7							
3	.1.	Date and Clock7							
3	.2.	Timer Settings							
3	.3.	Language9							
3	.4.	Boost9							
3	.5.	Information10							
3	.6.	Access							
4.	Serv	rice Menu							
4	.1.	Control Settings							
4	.2.	Fan Settings 13							
4	.3.	Filter Settings14							
4	.4.	BMS Communication Settings 15							
4	.5.	Sensors Settings							
4	.6.	User Authorization Settings17							
4	.7.	Heat Pump Settings							
4	.8.	VRF Settings							
5.	Con	figuration Menu							
5	.1.	Scenario Model19							
5	.2.	Fan Type 20							
5	.3.	After Heater 20							
5	.4.	Pre Heater 21							
5	.5.	Exchanger Frost							
5	.6.	On Board Inputs and Outputs 22							
5	.7.	External Module Inputs and Outputs 23							
5	.8.	Assignable Inputs List							
5	.9.	Assignable Outputs List							

1. Menu Tree



LISER	SETTINGS	
USER	SETTINGS	

SERVICE SETTINGS

FACTORY SETTINGS

2. Main Screen



1	Warning And Alarm Report	7	Warning Indicator
2	Fan Speed Level	8	Power Indicator
3	Working Mode	9	Climate Level
4	Function Button	10	System Clock
5	Setting Temperature	11	Communication State
6	Measuring Temperature	12	System Date

Main Menu Screen is mainly start screen of system. You can reach all screen from Main Screen. This screen designed user friendly with text and icon. Users use this screen for general operations, Setting Temperature, Setting Fan Level, On/Off system and View Working State of system.

2.1. Working Mode



Entering this menu follow this steps;

- Open main screen
- Push blue button at bottom side of screen

In this menu you can set Climate Type;

- Ventilation
- Heating
- Cooling
- Auto

If you want to change Climate Type just push any Climate Types and see blue bar on it. When see blue bar means you selected.

And you can change system Working State ON and OFF.

If you want to change Working State just push ON or OFF buttons and see blue bar on it. When see blue bar means you selected.

After that your selections will be saved when you push Function Button. Then you will return Main Screen and you will see your selections are working.

2.2. Set Temperature



This setting is system working temperature.

At the Main Screen, there is Temperature icon. Push this icon area at the middle of screen and then enter the Set Temperature screen.

If you want to increase value, you can push "+" button once or continuous touch. If you want to decrease value, you can push "-" button once or continuous touch. You can enter 10°C to 50°C temperature.

- 2.3. Fan Level Set

This setting is fan speed.

At the Main Screen, there is Fan icon. Push this icon area at the bottom of screen and then enter the Fan Level Set screen.

If you want to increase level, you can push "+" button once touch.

If you want to decrease level, you can push "-" button once touch.

You can enter 1 to 6 level. If you want fan level automatically to control by pressure or air volume. You can make fan level Auto for this feature.

2.4. Warning And Alarm Report



Warning and Alarm List				
Time (RTC)	ASP Tacho	Supply Air Temperature Sensor		
Communication Panel/Controller	HeatPump Compr. Termic	Return Temperature Sensor		
Communication BMS	HeatPump Pressure	Return Humidity Sensor		
Communication Module IO	HeatPump Low Pressure	Return CO2 Sensor		
Communication Cable Hum. Snr.	After Heater Termic	Return VOC Sensor		
Communication Cable CO2 Snr.	After Heater Limit	Fresh Air Temperature Sensor		
Communication Cable VOC Snr.	Pre Heater Termic	After Heater Temp. Sensor		
Communication DPS1 Snr.	Pre Hater Limit	Pre Heater Temp. Sensor		
Communication DPS2 Snr.	Filter Time Out	VNT Pressure Sensor		
Fire	Filter Dirty	ASP Pressure Sensor		
VNT Air Flow	VNT Filter Dirty	Device Turn ON		
ASP Air Flow	ASP Filter Dirty	Device Turn OFF		
Fan Error	Exchanger Frost	Device Wait Start		
VNT Fan Error	Battery Frost	Exchanger Frost / Soft		
ASP Fan Error	Battery Frost / Off	HeatPump Defrost		
Fan Error / Off	VRF Defrost	Fan Boost Enable		
VNT Fan Error / Off	No Control Temperature	Timer Enable		
ASP Fan Error / Off	Panel Temperature Sensor	External Start		
VNT Tacho	Room Temperature Sensor			

3. Main Menu



In this menu you can make system settings and you can enter service menu from this menu. If you want to enter this menu firstly you must at Main Screen and then you can enter with push Function Key right of screen than you can enter Main Menu.

3.1. Date and Clock



These settings are system real time clock settings.

This real time clock use for timer period and report of alarm and warning.

If you want to enter these menus, at Main Screen push function button than enter Main Menu and select Date or Clock symbol and push on symbols.

If you want to enter these settings, you can push "Date" and "Clock" icons at the Main Menu.

Which value you want to change, firstly push of value and see blue bar on it. After that you can push "-" for decreasing and push "+" for increasing value. Increase and decrease button you can push once or continuously.

After that your settings will be saved when you push Function Button.



3.2. Timer Settings

These settings are working time period and day settings.

If you want to enter these menus, at Main Screen push function button than enter Main Menu and select Timer symbol and push on symbol.

There are 4 time period. Set 1, Set 2, Set 3 and Set 4.

These settings have days of week. Each day, you can make active or passive. And each settings have Star Clock and Stop Clock. With these settings you can make 4 working period time in day.

02/01/23		00	07:00	
0		Ala	arm	
OK		07:01 - Device 07:01 - Device 07:01 - Timer E	Turn OFF Wait Start mable	

Note: If you set timer and time is in OFF period, you will see on main screen RED TIMER ICON and you can read info about system from report page. RED TIMER ICON means, the system is waiting for the ON time clock to starting. If you see GRAY TIMER ICON on main screen, system is ON time period and working.

3.3. Language



This setting is use for all menu language and alarm report text.

You can enter this menu, at Main Screen push function button than enter Main Menu and select Language symbol and push on symbol. If you want to change Language, select any Language and push on it. When see blue bar means you selected. After that your selections will be saved when you push Function Button.

3.4. Boost



This setting use for fan run full level.

You can enter this menu, at Main Screen push function button than enter Main Menu and select Boost symbol and push on symbol. After that you will hear buzzer bib. This means your fan start running full level until 15 minutes. If you need full capacity working fan at a time you can push this button.

3.5. Information



In this menu you can see software version and working scenario configurations information. You can enter this menu, at Main Screen push function button than enter Main Menu and select Information symbol and push on symbol.

3.6. Access



This setting is user password. These settings come from the factory as passive and 1234. When active state of password, every setting page enter with this password number.

- If forgot password, follow these steps;
- Power OFF system
- Hold down on function button at the right of screen
- Power ON system
- Access password is passive now
- You can enter Access menu and see password or change

4. Service Menu

\gg	 Service				
Service	Control	Fan			
	Filter	BMS Port			
	Sensor	Authorization			
	Configuration	Heat Pump			

In this menu you can set Service Settings and you can enter factory Configuration mode from this menu.

If you want to enter this menu you must follow bottom steps;

- System working mode make OFF
- Open Main Screen
- Push 3 seconds on Function button
- Hear buzzer beep
- Enter Main Menu
- Push Service Button

Attention: This menu is only for service personnel. The user should not make any change in this menu.

4.1. Control Settings



Restart:

- If select Active, when system electricity off and on after that the system continues to work from where it left
- If select Passive, when system electricity off and on after that the system always start in off.

Measure Point:

This is the temperature point to control.

Select which place do you need to control.

Note: The measure point temperature input you have selected must be assigned to the universal inputs. Note: This setting should be made by factory technicians.

Band Width:

This is the measure temperature and set temperature comparison range.



4.2. Fan Settings



In this menu you can set Aspiration and Ventilation Fans settings. Fan Limit:

With these settings you give limit for fan speed working area.

Fan Pressurize & PID:

With these settings use for fan pressure or volume control.

Note: These settings work only fan auto mode.

Calibration:

If you have 0-10V pressure sensor, you can use these settings for calibration.

4.3. Filter Settings



The time counter settings use for Filter Dirty warning message,

State :

- If select Active, when system working time pass over Time value then get filter dirty warning.
- If select Passive, this feature will not work.

Time:

This time set use for time count. Enter time value in hour.

Reset:

If occurs Filter Dirty Time warning, you can reset warning with this button.

4.4. BMS Communication Settings



These settings use for building management system connections.

You can set Address, Bound Rate and Parity Bit.

Note: If you want to use BMS Port, you must know registers address. You can get register address list from web or supplier.

4.5. Sensors Settings



These setting use for active sensors. You can add sensor, calibrate, change set value. There are three types of sensors.

- Humidity
- Carbon Dioxide
- Volatile Organic Compounds

State:

If you want to use sensor select connection type Cable or Active.

Cable type is our cost-effective sensor.

Active type is 0-10V outputs sensor.

Set:

Set is Fan full level working point.

If sensing value will be over of set, Fans run 6 level until measure value going down.

Calibration:

Calibrations settings use converting min and max sensor values to 0-10V.

4.6. User Authorization Settings

Authorization 💛	Authorization		
	Working State	Active	
	Working Mode	Active	
	Temperature	Active	
	Fan	Active	
	Timer	Active	
	Date & Clock	Active	

These setting use for user limit.

If Active user can be change setting, If Passive user cannot change setting.

4.7. Heat Pump Settings

Heat Pump	 Heat Pum	р
	Cycle Time	60
	Error Count	3
	Reset Time	6
	Process Time	10

These setting use for compressor.

Cycle Time:

Cycle times is heating to cooling and cooling to heating changing time.

Error Counter:

Error counter is low pressure error counter. With this counter, the system enter defrost mode.

Reset Time:

This error use for automatically resetting error counter. If in this time, error counter not reach to count number automatically reset error counter make zero.

Process Time:

The system remains in defrost mode during this time.

4.8. VRF Settings



This setting is use for VRF AHU kit.

The system work with two type of AHU Kit

Climate level and Set level.

If you have Climate level working AHU Kit, you can select Output Type is Climate Level. If you have Setting Temperature working AHU Kit, you can select Output Type is Set Temperature. After that you can calibrate Set Temperature 0-10V voltage outputs with P1 and P2 settings.

5. Configuration Menu

Configur ation →	Password					 	Configuration		
	Ċ			-			HRV Model	Fan Type	
	0 1		2	2 3 4		After Heater		Pre Heater	
	5	6	7	8	9		xchanger Fros	OnBoard IO	
	\bigcirc			0			Mdl. 10 State	Module 10	

5.1. Scenario Model



5.2. Fan Type

Fan Type	 Fan Type
	Radial
	EC
	Plug
	Belt Pulley
	3 Level

5.3. After Heater

After Heater ———	After He		
	Output Type	Module	 Level Binary Module
	Limit	60°	
	Period	120sc	

5.4. Pre Heater

Pre Heater	Pre He		
	State	Active	- Passive - Active
	Output Type	Module	- Level - Binary
	Temperature	0°	- Module
	Limit	60°	
	Period	120sc	

5.5. Exchanger Frost

kchanger Fro;───→	Exchanger	Frost	
	State	Passive	 Passive Active
	Temperature	0°	
	On Time	7	
	Off Time	2	

5.6. On Board Inputs and Outputs



5.7. External Module Inputs and Outputs



5.8. Assignable Inputs List



Digital Inputs			
Fire OFF	Compressor Pressures Error		
Fire Ventilation	Compressor High Pressure Error		
Fire Aspiration	Compressor Low Pressure Error		
	Compressor Thermic Error		
External Start			
	VRF AHU Kit Defrost		
Fans Error	VRF AHU Kit Fan Low Speed		
Ventilation Fan Error	VRF AHU Kit Fan Medium Speed		
Aspiration Fan Error	VRF AHU Kit Fan High Speed		
Fans Error Off (Fans Out OFF)			
Ventilation Fan Error OFF (VNT Out OFF)	Filter Dirty Pressure Switch		
Aspiration Fan Error OFF (ASP Fan OFF)	Ventilation Filter Dirty Pressure Switch		
Ventilation EC Fan Tacho	Aspiration Filter Dirty Pressure Switch		
Aspiration EC Fan Tacho			
	Exchanger Frost Pressure Switch		
Boost			
	Water Battery Frost Thermostat (Auto Reset)		
After Heater Thermic Error	Water Battery Frost Thermostat OFF(Manuel Reset)		
After Heater Limit Warning			
Pre Heater Thermic Error	Ventilation Fan Air Flow Pressure Swicth		
Pre Heater Limit Warning	Aspiration Fan Air Flow Pressure Switch		
Analog Inputs			
Ventilation Fan Air Pressure Sensor			
Aspiration Fan Air Pressure Sensor			
Room Temperature Sensor NTC10K			
Supply Air Temperature Sensor NTC10K			
Return Air Temperature Sensor NTC10K			

Return Air Humidity Sensor Return Air Carbon dioxide Sensor

Return Air Volatile Organic Compounds Sensor

Fresh Air Temperature Sensor NTC10K

After Heater Limit Temperature Sensor NTC10K

Pre Heater Limit Temperature Sensor NTC10K

5.9. Assignable Outputs List



Triac Outputs	Digital Outputs	Analog Outputs
Ventilation Fan Level	Working State	Ventilation Fan Ration
Aspiration Fan Level	Alarm State	Aspiration Fan Ration
	Bypass Damper	Climate Ration
	Air Inlet Damper	Cooler Ration
	Cooler	Heater Ration
	Heater	
	Ventilating Fan Start	
	Aspiration Fan Start	
	Ventilation Fan Level 1	
	Ventilation Fan Level 2	
	Ventilation Fan Level 3	
	Aspiration Fan Level 1	
	Aspiration Fan Level 2	
	Aspiration Fan Level 3	
	After Heater Out 1	
	After Heater Out 2	
	After Heater Out 3	
	After Heater Out PWM	
	Pre Heater Out 1	
	Pre Heater Out 2	
	Pre Heater Out 3	
	Pre Heater Out PWM	
	Compressor	
	4 Way Valve	